

INSTRUCTIONS & PICTURES NEEDED FOR INSPECTION:

WS0400DE

INSTRUCTION	SAMPLE IMAGE
<p>REQUIRED PHOTO 1</p> <p>Take a picture of the Model and Serial Number tag.</p> <p>PHOTO 1 REQUIRE Prenez une photo de l'étiquette indiquant le modèle et le numéro de série.</p> <p>FOTO REQUERIDA 1 Tome una foto de la etiqueta con los números de modelo y de serie.</p>	 <p>A close-up photograph of the back of the vacuum cleaner. A white label is affixed to the black plastic housing. The label contains the following text: 'SERIAL No. 1502590304', 'MODEL WD16800', '120V ~ 12A 60Hz', and 'Consumo de energía por unidad de tiempo en operación: 1.35 kWh'. To the right of the label is a circular opening, likely for a filter or dust container.</p>
<p>REQUIRED PHOTO 2</p> <p>Take a picture of the top portion of the blower that displays the handle and the switch.</p> <p>PHOTO 2 REQUIRE Prenez une photo de la partie supérieure de la soufflante qui montre la poignée et l'interrupteur.</p> <p>FOTO REQUERIDA 1 Tome una foto de la parte superior del soplador que muestre el mango y el interruptor.</p>	 <p>A close-up photograph of the top portion of the vacuum cleaner's blower. It shows a black plastic handle and a yellow trigger switch. The switch is in the 'off' position. There is some small, partially legible text on the plastic near the switch.</p>
<p>REQUIRED PHOTO 3</p> <p>Take a picture of the cord including the plug.</p> <p>PHOTO 3 REQUIRE Prenez une photo du cordon, d'alimentation, y compris de la fiche.</p> <p>FOTO REQUERIDA 3 Tome una foto del cable de alimentación, incluyendo el enchufe.</p>	 <p>A photograph of the power cord for the vacuum cleaner. The cord is black and is coiled. At the end of the cord is a standard two-prong electrical plug.</p>

INSTRUCTIONS & PICTURES NEEDED FOR INSPECTION:

WS0400DE

INSTRUCTION	SAMPLE IMAGE
<p>Remove the detachable blower from the lid. Place it upside down on the floor.</p> <p><i>Retirez la soufflante amovible du couvercle. Placez-la sens dessus dessous sur le sol.</i></p> <p><i>Retire de la tapa el soplador desmontable. Voltee el soplador y póngalo en el piso.</i></p>	
<p>Remove the three (3) screws holding the intake shield with a Phillips screwdriver.</p> <p><i>Retirez les trois (3) vis maintenant la plaque de protection de la prise d'air en place en utilisant un tournevis à pointe cruciforme.</i></p> <p><i>Retire los tres (3) tornillos que sujetan el escudo de la entrada utilizando un destornillador Phillips.</i></p>	
<p>REQUIRED PHOTO 4</p> <p>Next, lift out the intake shield to expose the blower wheel. Take a picture of the blower wheel through the hole. Center picture to focus on the nut shown.</p> <p>PHOTO 4 REQUIRE <i>Puis soulevez la plaque de protection de la prise d'air pour exposer la roue de soufflerie. Prenez une photo de la roue de soufflerie à travers le trou. Centrez la photo sur l'écrou montré.</i></p> <p>FOTO REQUERIDA 4 <i>Seguidamente, levante el escudo de la entrada para dejar al descubierto la rueda del soplador. Tome una foto de la rueda del soplador a través del agujero. Centre la foto para enfocar en la tuerca mostrada.</i></p>	